

Gentle Leader® Easy Walk™ Harness



Zeus

Instructions

IMPORTANT: Please be sure to read and understand all instructions before using the harness on your dog.


Identifying the parts:

- The chest piece has a martingale loop with a “D” ring for attaching the leash.
- The shoulder strap is made of the same color nylon as the chest strap and has the Premier fabric tag.
- The belly strap is made of a complementary color.

Fitting the harness:

- Open the quick snap buckle on the belly strap.
- Place the shoulder strap over the dog’s head with the chest strap resting on the dog’s chest.
- Tighten belly strap to a comfortably snug fit. On medium-sized dogs, only allow room for about a finger’s width under the strap. Allow a bit more for larger dogs, less for smaller dogs.

- Gently press fingers on lower front of dog’s chest to locate breastbone.
- Adjust the shoulder strap so that when the chest strap is horizontal (parallel to the ground), the chest strap rests directly over the breast bone.
- AFTER you have tightened both the shoulder and belly straps to allow only about a finger’s width under the strap, adjust the chest strap to fit securely. It should rest nearly parallel to the ground, not “hang down” or gap.
- You may need to remove the harness to make these adjustments.
- When the shoulder strap is fitted correctly, the chest strap should resemble a horizontal line (parallel to the ground), and it will rest directly over the breastbone.
- Attach the leash to the D-ring on the chest strap.



Using the harness:

The Gentle Leader® Easy Walk™ Harness is designed to gently discourage your dog from pulling while walking on a leash.

If your dog forges ahead of you, gently pull the leash to the side to turn the dog toward you. As he stops pulling, be sure to release the tension on the leash. Use praise and reward your dog with treats and/or petting.



Oliver

To slow your dog when he is pulling ahead, apply gentle pressure to the leash, pulling gently toward one side of the dog. Release the pressure on the leash when the dog is walking nicely next to you.

Like all collars, leashes, and harnesses, the Gentle Leader® Easy Walk™ Harness is a tool designed to help you train your dog to walk politely. We recommend finding a qualified trainer who can help you work with your dog in a positive way. For more information on finding skilled, professional trainers, contact the Association of Pet Dog Trainers at 1-800-PET-DOGS or visit their website at www.apdt.com.

We don’t recommend using the Gentle Leader® Easy Walk™ Harness with a retractable leash. With a retractable leash, the dog is “rewarded” with additional leash when he pulls ahead. We want the dog to

learn to NOT pull ahead. In addition, a retractable leash will always apply a slight constant pressure, teaching your dog it is okay to continue pulling.

We guarantee the materials and workmanship of Gentle Leader® Easy Walk™ Harness, but we can’t keep your dog from chewing it! Please be sure to supervise your dog while he wears the Easy Walk™ harness and store it safely when not in use. If your dog does chew the Easy Walk™, we will happily replace it for a \$15 fee. Call 888-640-8840 for details.

Check the fit regularly, especially on growing dogs. Examine the harness for signs of chewing, fraying, or damage. Do not leave the harness on your dog unattended.



Bentley